

PROGRAMMING INSTRUCTIONS #203

- 1. Access the green programming lead that is located behind the upper edge of the passenger side cowl trim panel. The lead has a red bullet connector at the end.
- 2. Jump the green programming lead to ground using a suitable jumper wire.
- 3. Turn ignition to the ON position.
- 4. Press any button on any of the remotes that need to be programmed, including any existing working ones. Door locks should cycle LOCK to UNLOCK after each remote has been entered, indicating the remotes have been accepted.
- 5. Remove jumper from the lead, turn the ignition OFF and remove the key before testing remotes for function.



DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.