

PROGRAMMING INSTRUCTIONS #206

- 1. Locate the Keyless Entry Program Line under the left side of the instrument panel. The line is a dark green wire with a molded plastic insulator on the end. The wire should be taped back to the harness to the left of the steering column near the floor.
- 2. Connect the end of the Keyless Entry Program Line to the ground using a suitable jumper wire.
- 3. Insert the key into the ignition and turn to the ON position.
- 4. Press any button on the first remote. The door locks will cycle LOCK to UNLOCK to confirm the remote has been added. If you have any other remotes (including any existing, working ones) they will also need to be added in this step. The locks should cycle after each remote has been added.
- 5. Disconnect the Keyless Entry Program Line from the ground, turn off the ignition and remove the key before testing each remote for function.



DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.