



## PROGRAMMING INSTRUCTIONS #209

**ATTENTION:** You **MUST HAVE** one working remote to add one more to the system. If you do not have one working remote right now then these instructions will not work. You will need a Locksmith or Dealer to complete the programming procedure.

You must obtain ALL remote transmitters you wish to program including all working ones. Any existing remote not used during programming will become inoperative.

1. Turn ignition to run position (as far as you can go without starting engine).
2. Using any Working remote, press the UNLOCK button for 4 to 10 seconds.
3. Within the specified 4 to 10 seconds, continue pressing the UNLOCK button and press the PANIC button for 1 second and release both buttons at the same time. A chime will sound within 3 seconds to indicate that the vehicle has entered remote programming mode.
4. Within 30 seconds of the chime, press and release the LOCK and UNLOCK buttons at the same time, then press the UNLOCK button on the remote. A chime should sound indicating the remote was successfully added.

**NOTE -** All remotes including any previously working ones need to be programmed during Step 4 above. You have 30 seconds to add each remote.

5. Turn ignition to OFF or wait 32 seconds to exit programming mode. A chime should sound indicating programming mode was exited.
6. Test all remotes.

**DISCLAIMER -** AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.