



PROGRAMMING INSTRUCTIONS #210

ATTENTION: You **MUST HAVE** one working remote to add one more to the system. If you do not have one working remote right now then these instructions will not work. You will need a Locksmith or Dealer to complete the programming procedure.

You must obtain ALL remote transmitters you wish to program including all working ones. Any existing remote not used during programming will become inoperative.

1. Turn ignition to run position (as far as you can go without starting engine) and wait for the chimes to stop.
2. Using any Working remote, press the UNLOCK button for 4 to 10 seconds.
3. Within the specified 4 to 10 seconds, continue pressing the UNLOCK button and press the PANIC button for 1 second and release both buttons at the same time. A chime will sound within 3 seconds to indicate that the vehicle has entered remote programming mode.
4. Within 30 seconds of the chime, press and release the UNLOCK button on the same remote. A chime should sound indicating the remote was successfully added.
5. For each remote you wish to add to the vehicle, including any existing ones, press and release the UNLOCK button. A chime will sound after each remote has been successfully added to the system.
5. Turn ignition to OFF to exit programming mode.
6. Test all remotes.

DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.