



PROGRAMMING INSTRUCTIONS #154

NOTE - This programming procedure requires at least one previously learned Master key. If you do not have a working key you will need to contact a locksmith or your dealer. The key-blade portion of this fob will be shipped to you uncut. You will need to have the key-blade cut to work with your vehicle before attempting the programming. The following procedure when completed will program both the transponder as well as remote functions.

1. With a previously working key, turn the ignition to the ON position (as far as you can go without starting the vehicle).
2. Turn the ignition OFF and remove the key.
3. Within 10 seconds insert the key to be learned and turn the ignition to the ON position (as far as you can go without starting the vehicle). Turn the ignition back OFF and remove the key.
4. The new key has now been added. Test for function.

DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.