

PROGRAMMING INSTRUCTIONS #502

- 1. Locate the VALET/OVERRIDE switch under the driver's side dash and switch it to the ON position.
- 2. With the key turn the ignition to ON and then back to OFF.
- 3. Flip the VALET/OVERRIDE switch to OFF and the ON to OFF two times. The system should respond with a chirp.
- 4. Turn the key in the ignition to ON and back to OFF two times and the system should again respond with a chirp.
- 5. Push the GREEN button on the first remote you wish to program and if programming a second, within 5 seconds press the GREEN button on that remote. The system should chirp after each remote is accepted.

NOTE - Programming mode will automatically terminate 5 seconds after you enter it. If you do not press the remote buttons quick enough you will need to start over at Step 1.

