



PROGRAMMING INSTRUCTIONS #103

NOTE - It is recommended that a diagnostic tool be used for programming as this procedure only programs the remote portion and does NOT program the key if the vehicle is equipped with a transponder. To complete remote programming using the procedure below you MUST have 2 working keys.

1. Insert the first working key into the ignition and turn to the ON position. DO NOT START THE VEHICLE.
2. Exit the vehicle and close the Driver door, make sure all other doors and trunk are closed.
3. With the key to be programmed LOCK the Drivers door.
4. Press ANY button on the new remote and release, pause for 2 seconds, press the same button again and release.
5. A tone from the horn confirms the remote has been accepted.
7. Unlock the drivers door, remove the key from the ignition and re-lock all doors with a key before testing the remote.

DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.