



## PROGRAMMING INSTRUCTIONS #202

NOTE - Any existing remotes not used during this procedure will become inoperative.

1. Obtain all remotes you wish to program, including any existing, working ones.
2. Open the Driver's door and manually LOCK it using the interior door lock button.
3. Turn ignition to the ON position.
4. Within 20 seconds, point the remote at the receiver in the roof lining and press the LOCK button for at least 5 seconds. The driver's door will unlock when the remotes has been accepted.
5. To program any additional remotes you will need to again manually LOCK the driver's door using the switch and point the next remote at the receiver in the roof lining and press and hold the LOCK button for at least 5 seconds.
6. Once all remotes have been programmed you must cycle the key in the ignition from ON position, back to OFF and then back to ON to exit preprogramming mode.

NOTE - This remote system works off IR and you MUST point the remote DIRECTLY at the receiver dome for the remote to be accepted.

DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.