



## PROGRAMMING INSTRUCTIONS #273

1. TURN ignition from OFF to ON 4 times within 3 seconds. Door locks should cycle to confirm entry into programming mode.
2. Within 7 seconds press ANY button on the first remote. Door locks should cycle to confirm the remote has been accepted.

NOTE - All additional remotes, including any any previously working ones will need to be programmed using Step 2 above.

3. To EXIT programming mode wait 7 seconds after programming the last remote and turn ignition OFF.

NOTE - You may have to wait 20 or more seconds after closing programming mode before the remotes will function.