



## PROGRAMMING INSTRUCTIONS #280

1. With the driver door left OPEN. TURN ignition from OFF to ON eight (8) times within 10 seconds. Door locks should cycle to confirm entry into programming mode.
2. Within 7 seconds press ANY button on the first remote. Door locks should cycle to confirm the remote has been accepted.

NOTE - All additional remotes, including any previously working ones will need to be programmed using Step 2 above.

3. To EXIT programming mode turn the ignition back to OFF.

NOTE - You may have to wait 20 or more seconds after closing programming mode before the remotes will function.