




## PROGRAMMING INSTRUCTIONS #280

1. With the driver door left OPEN. TURN ignition from standby to ON  eight (8) times within 10 seconds, where standby is the semi-position between on & off. Door locks should cycle to confirm entry into programming mode.
2. Within 7 seconds press ANY button on the first remote. Door locks should cycle to confirm the remote has been accepted.

NOTE - All additional remotes, including any previously working ones will need to be programmed using Step 2 above.

3. To EXIT programming mode turn the ignition back to OFF.

NOTE - You may have to wait 20 or more seconds after closing programming mode before the remotes will function.