



## PROGRAMMING INSTRUCTIONS #300

1. Locate the Security System Control Unit underneath the driver's seat.
2. Turn the ignition to the ON position.
3. PRESS and HOLD the GREEN programming button on the side of the unit. The button is in a hole in the side of the unit about the size of a pen or pencil. Do not release the button until the security system LED on the instrument panel comes on.
4. Within 5 seconds PRESS and RELEASE the top button on the remote. The LED will go out, the siren will chirp and the front marker lights will flash confirming the remote has been accepted.
5. To program any additional remotes repeat Steps 3 and 4 above.
6. Turn ignition OFF and remove the key before testing the remotes for function.

DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.