



## PROGRAMMING INSTRUCTIONS #427

1. Gain access to the Remote Keyless Entry (RKE) receiver module. Refer to the owner's manual for trim panel removal instructions.

NOTE - Receiver Manual Locations:

- \* EXPO LRV and SUMMIT WAGON is on the driver side behind the rear quarter trim panel at "C" pillar, above rear wheel well (passenger side on EXPO)
- \* MONTERO is behind rear quarter panel, forward of the passenger side rear combination light.
- \* DIAMANTE and GALANT is under rear shelf trim (access from trunk except on 1997 and up DIAMANTE)
- \* 300GT is behind the rear quarter panel trim on the driver's side, near left rear speaker.

2. The switch on the receiver module has 3 positions: SET I, FIX and SET II. In the normal operating position the switch should be set in the FIX (middle).  
To program the remotes, first move the switch to one of the SET positions.
3. Press either the LOCK or UNLOCK button on the first remote.
4. Move the switch on the receiver module to the FIX position.
5. Press either the LOCK or UNLOCK button on the second remote.
6. Move the switch on the receiver module to the FIX position.
7. Remove the ignition key from the ignition and close all the doors and trunk (or hatch).
8. Verify both remotes operate correctly.

DISCLAIMER - AutoRemotes.ca accepts no responsibility for content, accuracy, or any other problems that may occur from the use of these programming instructions.