



PROGRAMMING INSTRUCTIONS #454

NOTE - You must have all remotes present at time of programming, including any existing, working ones.

1. Sit in the Driver's seat and have all of the doors and windows, trunk and hood closed.
2. Turn the Alarm Console Switch in the "ALARM OFF" position.
3. Cycle a key in the ignition to ON (as far as you can go without starting the vehicle) and then back to OFF 6 (six) times within 10 (ten) seconds.
NOTE - You should end this step with the key in the OFF position.

4. Move the Alarm Console Switch from the ALARM OFF position to AUTO and then back to ALARM OFF.

5. Press the LOCK/UNLOCK button on the remote once.

NOTE - To program the additional remotes, including any previously working ones repeat Step 4 and Step 5 for each remote.

6. Open the driver door to close the programming procedure and test remotes for function.