



## PROGRAMMING INSTRUCTIONS #501

1. Locate the Keyless Entry Module under the driver's side dash.
2. Using a small screwdriver push down the switch located next to the RED LED until the light begins to flash.
3. Press and release the LOCK button on the remote. The LED will respond by staying lit momentarily and then begin to flash again.
4. If there is a second remote repeat Step 3.
5. The programming cycle is closed after the LED stops flashing.